




F16 Z




F16 3




F3.40




F16-5A






F16 63

F16-6A



FIFBA



FILME

RELEASE CHILD SAFETY BY LIFTING THE SPRING LIADED SLIDER UP USING INDEX FINGER




FIL-80

IGNITOR AT REST WITH CHILD SAFETY RESET AND IGNITOR SHUT DFF

FUFBC

WHILE HOLDING CHILD SAFETY RELEASE SLIDER UP, SQUEEZE TRIGGER TO LIGHT IGNITOR






FIG 10A

#1/6

